HOME THEATER SYSTEM Power Distribution

Rev 17.2

Enter Component Number in box
Component data will auto fi

"A"

34

| 30 | = DVD/SACD/CD Changer |
| A1 | 24 Watts |

| 16 | = DVD/SACD |
| A2 | 20 Watts |

| # | = SPARE |
| A3 | - Watts |

| 1 | = VCR |
| A4 | 24 Watts |

| 45 | = XBOX 360 Console |
| A5 | 600 Watts |

| 46 | = 2-Channel Power Amplifier |
| A6 | 800 Watts |

"A"

Volts = 120.0
Hz = 60
Watts = 1,468
Amps = 12.23

"B"

34

| 31 | = 5-Channel Power Amplifier |
| B1 | 800 Watts |

| 2 | = A/V Receiver |
| B2 | 280 Watts |

| # | = SPARE |
| B3 | - Watts |

| # | = SPARE |
| B4 | - Watts |

| 11 | = Rear Projection-TV |
| B5 | 230 Watts |

| 6 | = Sub-Woofer |
| B6 | 351 Watts |

"B"

Volts = 120.0
Hz = 60
Watts = 1,661
Amps = 13.84

33

47

WP-1

33

47

WP-17

38

CHSP

66

64   65

N   GND

200A

27   15A
29   15A
31   15A
33   15A

Loadcenter